


142, 20064900001-20070100000


SPARE PARTS LIST

PARTS LIST NO. 530165248		© PARTS LIST	CHAIN SAW MODEL(s) 142 North America
DATE 12/14/06	Replaces 530165248 - 5/19/06		PAGE NO. 5
Note: Illustration may differ from actual model due to design changes			



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
30	530015940	SCREW		1	
31	530029870	INSULATOR		1	
32	530055613	FUEL TANK		1	
33	530015843	SCREW		1	
34	530059961	HANDLE		1	
35	530052439	MOVEMENT LIMITER		1	
36	530029984	LIMITER		1	
37	530026119	CHECK VALVE		1	
38	530038264	PLUG		1	
39	530071266	FUEL CAP		1	

PARTS LIST NO. 530165248		® PARTS LIST	CHAIN SAW MODEL(S) 142 North America
DATE 12/14/06	Replaces 530165248 - 5/19/06		Note: Illustration may differ from actual model due to design changes





REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
14	530071967	IGNITION MODULE		1	
15	530403257	CABLE		1	
16	530015896	SCREW		1	
17	503717901	STOP SWITCH		1	
18	530059637	FLYWHEEL ASSY		1	
19	530015127	WASHER		1	
20	530016134	NUT		1	
21	545003902	SCREW		1	
22	545063901	MODULE IIDA IGNITION		1	

PARTS LIST NO. 530165248		Husqvarna® PARTS LIST	CHAIN SAW MODEL(s) 142 North America
DATE 12/14/06	Replaces 530165248 - 5/19/06		Note: Illustration may differ from actual model due to design changes


⚠ WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	530014949	CLUTCH		1	
2	530015611	WASHER		1	
3	530047061	CLUTCH DRUM ASSY		1	
4	530015907	WASHER		1	
5	530014776	OIL PICK-UP		1	
6	530056533	SCREEN		1	
7	545037101	SEALING		1	
8	530015896	SCREW		1	
9	530014410	OIL PUMP		1	
10	530029833	PUMP		1	

PARTS LIST NO. 530165248		Husqvarna® PARTS LIST	CHAIN SAW MODEL(s) 142 North America
DATE 12/14/06	Replaces 530165248 - 5/19/06		PAGE NO. 3
Note: Illustration may differ from actual model due to design changes			




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
23	530056363	BEARING		1	
24	530029794	CRANKSHAFT		1	

PARTS LIST NO. 530165248		Husqvarna® PARTS LIST	CHAIN SAW MODEL(s) 142 North America
DATE 12/14/06	Replaces 530165248 - 5/19/06		Note: Illustration may differ from actual model due to design changes




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	530029879	SCREW		1	
2	530071348	LEVER		1	
3	530015915	SCREW		1	
4	530054741	KNEE LINK		1	
5	530016237	SPRING		1	
6	530016384	SCREW		1	
7	530056531	SHAFT PIVOT		1	
8	530029881	SHAFT PIVOT		1	
9	530024419	E-CLIP		1	
10	530015911	SCREW		1	
11	530015913	PEN		1	
12	530029878	SPRING		1	
13	530015910	SPRING		1	
14	530052232	BRAKE BAND		1	
530054802	530054802	CHAIN BRAKE ASSY		1	
545090701	545090701	CHAIN BRAKE		1	
16	530053035	COVER		1	
17	530015911	SCREW		1	

PARTS LIST NO. 530165248		® PARTS LIST	CHAIN SAW MODEL(S) 142 North America
DATE 12/14/06	Replaces 530165248 - 5/19/06		NOTE: Illustration may differ from actual model due to design changes




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	530071968	STARTER DEVICE		1	
2	530071966	STARTER PULLEY		1	
3	530150318	HANDLE		1	
4	530069232	STARTER ROPE		1	
5	530021179	SCREW		1	
6	530059677	SLEEVE		1	
7	530021180	SPRING		1	
8	530016080	SCREW		1	
9	530042095	SPRING		1	
10	530059959	BAFFLE		1	
11	530059958	STARTER		1	
12	530015893	SCREW		1	
13	530015892	SCREW		1	

PARTS LIST NO. 530165248		Husqvarna® PARTS LIST	CHAIN SAW MODEL(s) 142 North America
DATE 12/14/06	Replaces 530165248 - 5/19/06		Note: Illustration may differ from actual model due to design changes




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
17	530071511	SILENCER		1	
18	530016359	NUT		1	
19	530055600	WASHER		1	
20	530016338	BOLT		1	
21	530055128	GASKET		1	
22	530055171	COUVERCLE		1	

PARTS LIST NO. 530165248		Husqvarna® PARTS LIST	CHAIN SAW MODEL(s) 142 North America
DATE 12/14/06	Replaces 530165248 - 5/19/06		Note: Illustration may differ from actual model due to design changes



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
530049483	530049483	CLUTCH COVER		1	
545051101	545051101	COVER		1	
22	545060101	ASSEMBLY		1	
24	545060201	GEAR		1	
25	545060501	PIN BAR ADJUSTING		1	
26	545060401	ADJUSTMENT SCREW		1	
27	545051201	COVER		1	
28	530016064	SCREW		1	
530031135	530031135	WRENCH		1	
530047839	530047839	DECAL		1	

PARTS LIST NO. 530165248		 Husqvarna® PARTS LIST	CHAIN SAW MODEL(s) 142 North America
DATE 12/14/06	Replaces 530165248 - 5/19/06		Note: Illustration may differ from actual model due to design changes




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
3	952030150	SPARK PLUG		1	
4	530069941	CYLINDER		1	
5	530069454	PISTON		1	
6	530029982	PISTON RING		1	
7	530015697	LOCKING RING		1	
8	530049794	CRANKCASE		1	
9	530015897	SCREW		1	


PARTS LIST NO. 530165248		Husqvarna® PARTS LIST	CHAIN SAW MODEL(s) 142 North America
DATE 12/14/06	Replaces 530165248 - 5/19/06		Note: Illustration may differ from actual model due to design changes

⚠ WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.




REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	530016154	SCREW		1	
2	530059960	CYLINDER COVER		1	



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
23	530029869	THROTTLE ROD		1	
24	530029863	HUB CAP		1	
25	530029860	SCREW		1	
26	530029861	SPRING		1	
27	530069587	THROTTLE TRIGGER		1	
28	530069247	HOSE		1	
29	530014497	FILTER		1	


PARTS LIST NO. 530165248		Husqvarna® PARTS LIST	CHAIN SAW MODEL(s) 142 North America
DATE 12/14/06	Replaces 530165248 - 5/19/06		Note: Illustration may differ from actual model due to design changes



WARNING
 All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.


REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	530029813	JET		1	
2	530019203	SEALING		1	
3	530029814	PIPE		1	
4	530053435	HOSE		1	
5	530015814	SCREW		1	
6	530037465	ADAPTER		1	
7	530019172	GASKET		1	
8	530071987	CARBURETTOR		1	
9	530035587	PASSAGE		1	
10	530047767	SUPPORT		1	
11	530015896	SCREW		1	
12	530036582	HOLDER		1	
13	530015968	SCREW		1	
14	530016008	NUT		1	
15	545057801	AIR FILTER COVER		1	
16	530015899	SCREW		1	

PARTS LIST NO. 530165248		Husqvarna® PARTS LIST	CHAIN SAW MODEL(s) 142 North America
DATE 12/14/06	Replaces 530165248 - 5/19/06		Note: Illustration may differ from actual model due to design changes



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
11	545033501	HOSE		1	
12	530055322	NUT		1	
13	530055174	PROTECTION		1	
14	530015896	SCREW		1	
15	530015917	NUT		1	
16	530047855	PLATE		1	
17	530019228	SEALING		1	
18	530036043	SUPPORT		1	
19	530015877	BOLT		1	
20	530015878	SCREW		1	
21	530029850	CHAIN CATCHER		1	
22	530015893	SCREW		1	
23	530052428	COVER		1	
24	530015922	NUT		1	
25	530029830	GUIDE		1	
26	530029831	CHOKE CONTROL		1	
27	530071991	CRANKCASE		1	
28	530015922	NUT		1	
29	530016037	SCREW		1	
30	501765602	TANK CAP ASSY		1	


PARTS LIST NO. 530165248		Husqvarna® PARTS LIST	CHAIN SAW MODEL(s) 142 North America
DATE 12/14/06	Replaces 530165248 - 5/19/06		Note: Illustration may differ from actual model due to design changes



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
18	530016110	SCREW		1	
19	530038593	RETAINER		1	
20	530015826	PEN		1	

PARTS LIST NO. 530165248		Husqvarna® PARTS LIST	CHAIN SAW MODEL(s) 142 North America
DATE 12/14/06	Replaces 530165248 - 5/19/06		Note: Illustration may differ from actual model due to design changes

Kit - Carburetor Assembly No. 530071987 - Zama W-29



Carb
Repair
Kit
1

Ref.	Part No.	Description
1.	530035269	Kit-Carburetor Repair (Zama)

⚠ WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

✓ = NEW PART NUMBER FOR THIS IPL * = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)
● = THESE PARTS ARE ILLUSTRATED FOR CLARITY. ORDER COMPLETE ASSEMBLY.

REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	530035269	REPAIR KIT		1	